



USP ULTRA SMOOTH PLASTER

SKIM COAT PUTTY FOR WOOD JOINTS, NAIL HOLES, EXTERIOR AND INTERIOR WALLS, TILE GROUT, BUILDING JOINTS AND DOOR FRAMES.



USES

- For grouting Wood Joint and holes, pre-cast wall joint, tile joints, doorframe, aluminum window. Can replace silicone sealant suitably
- A White or Colored Finishing Skim Coat, for putting into crack or uneven wall or ceiling in a one-step operation, achieving ultra-smooth finish. Color pigment can be added at site.
- Can be painted on directly without primer coat
- It will cover tiny holes, fine crack, joint and dent on wood, cement and gypsum surface without adding too much thickness
- Added with water, it can be used as white or color paint

FEATURES

- Bond strength exceeds 0.8 mpa, hard and breathable, it does not shrink and crack and is not powdery. Water and alkaline resistance
- Water-based, no unpleasant odor, non-toxic wall finishing material.
- Suitable under clear finishes including lacquer and polish as well as paint.

APPLICATION METHOD

- Dampen the wall surface before troweling **USP ULTRA SMOOTH PLASTER**.
- Apply 2 to 3 coats, about 2 to 3 mm per coat. Drying time is about 60 minutes.
- When it is about 80 % dry and hardened, use a stainless steel trowel to press and smoothen the surface, to achieve mirror finish.
- Scratch mark can be re-smoothened by wetting with a paintbrush. No sanding and painting needed.
- Old wall surface usually has acidic residue, treat the surface with sealer e.g. FLEXI-CLEAR to prevent yellowing.
- **USP SMOOTH PLASTER** can be diluted with water and used as paint. Spray or roll over the entire wall to achieve white even finishes.

WARRIOR PTE LTD

Blk 17 Marsiling Industrial Estate Road 1 # 01-11 Singapore 739279

Tel: (65) 6364 5100 / 6364 5060 / 6367 3676 Fax: (65) 6364 0629

war99@singnet.com.sg www.warrior.com.sg





USP ULTRA SMOOTH PLASTER

SKIM COAT PUTTY FOR WOOD JOINTS, NAIL HOLES, EXTERIOR AND INTERIOR WALLS, TILE GROUT, BUILDING JOINTS AND DOOR FRAMES.

- For timber, press putty lightly into position, leaving a little standing slightly proud of the surface. For deeper holes a second application should be made after the fast coat has hardened sufficiently. Remove all traces of sanding dust prior to application of other coatings.

REMARKS

- Do not carry out the application whilst painting is in progress to avoid yellowing of the USP PLASTER. Do not soil the wooden surface to avoid discoloring
- Do not mix with other plaster.
- Colour can be customised upon request.

PACKING

10 x 2 kg - poly bag (in 20 litre-pail) / 5 litre - plastic-pail / 10 litre- plastic pail

***Disclaimer:** The information provided in this brochure is ensured to be as accurate as possible at the time of inclusion, however there may be inadvertent and occasional errors which may have slipped from our notice. Warrior Pte Ltd does not guarantee and make no representations or warranties of any kind about the information, advice and opinions provided and reserves the right to make changes and corrections at any time, without prior notice to any parties. Warrior Pte Ltd accepts no liability for any inaccuracies or omissions in its brochure and any decisions made based on information and opinions contained in the brochure is the sole responsibility of the user.*

WARRIOR PTE LTD

Blk 17 Marsiling Industrial Estate Road 1 # 01-11 Singapore 739279

Tel: (65) 6364 5100 / 6364 5060 / 6367 3676 Fax: (65) 6364 0629

war99@singnet.com.sg www.warrior.com.sg

